

V

## DEPARTURE ROUTE DESCRIPTION

PUTTY 2C TAKE-OFF RWY 29: As soon as practicable after take-off turn left heading 261° to intercept NIK VOR/DME R-081, cross BUB VOR/DME R-345 at or above 450 then turn right to intercept BUB R-347 to PUTTY.

<u>PUTTY 1E TAKE-OFF RWY 11: Climb runway heading to WW NDB, then turn left outbound WW bearing 098° until crossing BUB VOR/DME R-006, then turn left heading 278° to intercept BUB R-347 to PUTTY.</u>